


## 4.8v Cordless Screwdriver Instructions for Use

For your safety, please read all instructions carefully before using this tool. This power tool is designed for DIY use only and is not meant for industrial use.

### Safety Instructions

- a) Do not use machines, attachments, and chargers for work other than those for which they are designed.
- b) Before you lay down the drill/screwdriver, make sure all moving parts have come to a complete stop.
- c) Do not wear loose fitting clothing or jewelry while operating drill.
- d) Wear protective gear ie.: safety goggles, work gloves, masks or respirator.
- e) Never pull on cord to unplug the drill from a wall outlet.
- f) Always keep cord away from moving parts of the tool.
- g) Disconnect the drill when not in use or before performing any maintenance or changing accessories.
- h) STOP THE MACHINE IMMEDIATELY IN CASE OF: Defective plug or electrical cord or defective switch or sparks, smoke or burning smell.
- i) Avoid frequent stalling when screwing or drilling, this could damage the battery.
- j) Only connect the charging device to a 110v outlet.
- k) Protect the charging device and screwdriver from moisture.
- l) Never expose batteries to temperatures above 120 degrees F.
- m) Do not short out the contacts of battery or charger.
- o) Do not throw batteries in fire.



1. On/Off Switch (Trigger)
2. LED Light
3. Screw Bit Holder
4. Charging Socket
5. Charger Plug
6. Charger
7. LED On/Off Button
8. Battery Level Indicator
9. Battery Built-In
10. Screwdriver Handle
11. Angle Adjustment Button
12. Forward/Reverse Selection


**Charging:** Charge the screwdriver for 5-8 hours before initial use. To charge, insert the charger plug (5) into the charging socket (4) and connect the charging unit (6) to a power supply. Do not exceed the maximum charging time of 8 hours.

**Operation:** Insert the desired screwdriver bit into the bit holder (3) as far as the stop. Before switching on the screwdriver unit, align the bit to the screw. To operate, depress the trigger (1). To change the direction of rotation, push the Forward/Reverse switch (12).

**Manual Operation:** The screwdriver has an automatic spindle lock function that will prevent the drill from turning on accidentally. When neither the forward/reverse (12) direction is selected, the trigger (1) will not depress. This feature can also be used on a tight screw that needs to be turned manually.

**Battery Level Indicator:** Displays green/yellow/red to indicate the power level of the battery.

**LED Light:** Press the button (7) to turn on or off.



**Angle Adjustment:** Allows the conversion from a pistol grip to a straight grip. Depress the lock switch (A), and rotate the handle grip clockwise until lock is fully engaged in the straight position.

**Cleaning and Maintenance:** Wipe clean using a damp cloth. Do not use chemical detergents or solvents to clean, this may damage plastic parts. Ensure the ventilation slots are kept clean and free of debris. When storing the product for long periods of time, it is recommended that the battery be recharged periodically (approximately every 3-4 months). Long periods of inactivity may cause damage or reduce the capacity of the internal battery.

TECHNICAL SPECIFICATION	
Rated Voltage	DC 4.8V
No-load Speed	200 min <sup>-1</sup>
Battery Type	1.2 V NI-MH
Charger	300 MAH
Rated Voltage	120V, 60Hz
Output Voltage	6V
Bit Size	1/4" (6.35mm)
Max Torque	2.5NM
Charging Time	5-8 hours